

# Atlas Copco Instruction Manual



Instruction Manual  
For Portable Light Tower Generator  
English

HiLight V4  
HiLight V5+

| Engine Kubota Z482

*Atlas Copco*



**Instruction Manual  
For Portable Light Tower Generator**

**HiLight V4  
HiLight V5+**

Engine Kubota Z482

**Original instructions**

Printed matter N°  
9829 3827 01

09/2016



---

ATLAS COPCO - PORTABLE ENERGY DIVISION  
[www.atlascopco.com](http://www.atlascopco.com)

---

### **Warranty and Liability Limitation**

Use only authorized parts.

Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

The manufacturer does not accept any liability for any damage arising from modifications, additions or conversions made without the manufacturer's approval in writing.

Neglecting maintenance or making changes to the setup of the machine can result in major hazards, including fire risk.

While every effort has been made to ensure that the information in this manual is correct, Atlas Copco does not assume responsibility for possible errors.

Copyright 2016, Atlas Copco Airpower n.v., Antwerp, Belgium.

Any unauthorized use or copying of the contents or any part thereof is prohibited.

This applies in particular to trademarks, model denominations, part numbers and drawings.

## Preface

Please read the following instructions carefully before starting to use your light tower.

It is a solid, safe and reliable machine, built according to the latest technology. Follow the instructions in this booklet and we guarantee you years of troublefree operation.

Always keep the manual available near the machine.

In all correspondence always mention the light tower type and serial number, shown on the data plate.

The company reserves the right to make changes without prior notice.



## Table of contents

<b>1</b>	<b>Main parts - HiLight V4</b> .....	6
<b>2</b>	<b>Main parts - HiLight V5+</b> .....	7
<b>3</b>	<b>Safety Information</b> .....	8
3.1	Operating Safety.....	8
3.1.1	Prior to use.....	8
3.1.2	During operation.....	8
3.2	Engine safety.....	9
3.2.1	Operator safety.....	9
3.3	Service safety.....	10
3.3.1	Before servicing.....	10
3.3.2	During servicing.....	10
3.4	Labels.....	11
<b>4</b>	<b>Assembly</b> .....	17
4.1	Tow hitch.....	17
4.2	Loose parts.....	17
4.3	Light fixtures.....	18
<b>5</b>	<b>Operation</b> .....	19
5.1	Safety.....	19
5.2	Control panels.....	19
5.3	Towing and hoisting.....	19
5.3.1	Before towing.....	19
5.3.2	During towing.....	20
5.3.3	After towing.....	20
5.3.4	Hoisting.....	20
5.4	Location.....	21
5.5	Deployment.....	22
5.5.1	Levelling the trailer.....	22
5.5.2	Raising the tower.....	22
5.5.3	Lowering the tower.....	24



5.5.4	Engine operation.....	25
5.5.5	Lights.....	26
5.6	Floodlight lux level.....	27
<b>6</b>	<b>Maintenance</b> .....	30
6.1	Daily inspection.....	30
6.2	Lamp replacement.....	30
6.3	Servicing the engine.....	30
6.4	Replacement parts.....	30
6.5	Wiring diagrams.....	31
<b>7</b>	<b>Circuit diagram</b> .....	32
<b>8</b>	<b>Axle maintenance manual</b> .....	56
8.1	Axle.....	56
8.1.1	Safety Precautions.....	57
8.1.2	Maintenance.....	57
8.1.3	Operation.....	57
8.2	Wheel bolt tightening torque.....	57
8.3	U-bolt nut tightening torque.....	57
<b>9</b>	<b>Setting the Lc1003™ controller</b> .....	58
9.1	Push button and LED functions.....	58
9.2	Module display.....	59
9.3	Home page.....	59
9.4	Icon overview.....	59
<b>10</b>	<b>Maintenance</b> .....	65
10.1	Maintenance schedule.....	65
<b>11</b>	<b>AML Data</b> .....	68
<b>12</b>	<b>Option</b> .....	73
<b>13</b>	<b>Dimensional drawing</b> .....	76

# Main parts - HiLight V4

"The light tower provides an undercarriage ( frame, axle and towbar ) and 4 floodlights of 1000 W each or 4 LED floodlights of 350 W each. The light tower is very useful for construction sites where neither electricity nor lighting is available."



# Main parts - HiLight V5+



# Safety Information

## Operating Safety



### **WARNING**

**Improper use of equipment could cause serious injury or death.**

Prior to using this product, carefully read, understand, and observe all instructions in this manual and the engine manual.



### **CAUTION**

**Crush hazard.**

When operating or working on the light tower, keep hands and body parts clear of pinch points.

## Prior to use

To reduce the risk of personal injury, ensure the surrounding area is in good order and free of debris.

To reduce the risk of shifting, rolling, or overturning, locate the light tower on a firm, level surface, with enough space to deploy the trailer's outriggers.

Do not allow water to accumulate around the base of the light tower.

To improve stability, deploy the outriggers prior to raising the light tower mast.

The light tower mast can be extended to 24.6 feet (7.5 m) in height. Ensure the area above the trailer is clear of obstructions.



### **DANGER**

**Electric shock hazard.**

**Contact with overhead electrical power lines will cause serious injury or death.**

Do not position light tower under power lines.

Ensure the light tower is in good operating condition:

Check tires, lights, protective lamp covers, electrical wiring, and the engine for obvious signs of wear or damage.

Never use any equipment that is damaged or in need of repair.

## During operation

### **WARNING**

**Falling equipment could cause serious injury or death.**

When raising or lowering the light tower mast, ensure the area directly behind the trailer is clear of people.

If the mast “hangs up” or the winch cable develops slack while raising or lowering the mast, stop immediately, move away from the unit and contact Atlas Copco.

- Ensure the trailer is well grounded, per all applicable regulations.
- Never raise, lower, or move the trailer while the light tower is in use.
- Do not collapse the outriggers or move the trailer while the light tower mast is extended.
- When not in use, or in case of high winds, lower the light tower mast to the travel position (see page 24).
- Light bulbs can be extremely hot. Always allow bulbs to cool at least 15 minutes before handling.



 **CAUTION**

**Risk of severe burn.**

Before handling lights, allow lights to cool for 15 minutes.

## Engine safety

### Operator safety



 **DANGER**

**Explosion hazard.**

- Keep engine, fuel, and other combustibles away from sparks, open flame, and burning objects.
- Do not smoke near engine.
- Stop engine before filling or draining fuel tank.
- Use only diesel fuel.
- Re-place fuel tank cap after refuelling.
- Do not use gasoline, other fuels, or flammable solvents to clean parts.



 **DANGER**

**Asphyxiation hazard.**

- Operate the engine outdoors and keep away from engine exhaust.
- If operating in an enclosed area, vent exhaust fumes to outdoors and maintain adequate ventilation.
- Refill and drain fuel tank only in a well ventilated area.
- Perform maintenance in a well ventilated area.



 **WARNING**

**Fire hazard.**

**A hot muffler can ignite flammable materials.**

Keep area around muffler free of debris such as leaves, paper, and cartons.

**CAUTION****Risk of severe burn.**

- Do not touch the engine, exhaust pipes, or areas near the exhaust at rear of trailer.
- Do not remove radiator cap when engine is hot. Contents are hot and under pressure.

## California Proposition 65

**DANGER****Health hazard.**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

## Spark arresters

**IMPORTANT!**

State and local safety codes specify that, in certain locations, internal combustion engines that use hydrocarbon fuels must be used with spark arresters.

A spark arrester is a device constructed of nonflammable materials specifically for the purpose of removing and retaining carbon and other flammable particles from the exhaust flow of an internal combustion engine.

## Service safety

### Before servicing

**DANGER****High voltage.**

**Contact with live electrical circuits will cause severe injury or death.**

- Turn off power before servicing any component on the light tower.
  - Only a qualified electrician should service the light tower electrical system.
- ∞ Never perform even routine service (such as changing oil and filters, or cleaning the engine) unless all electrical components are shut down:
    - Ensure all light tower power circuits are shut off.
    - Turn the engine key to OFF and set all circuit breakers to the OFF position.
    - Disconnect cable from negative terminal on battery.
  - ∞ If the ground under or around the trailer is damp or wet, move the trailer to a dry location and allow it to dry before servicing. Do not allow water to accumulate around the base of the light tower.
  - ∞ Do not service the light tower if clothing or skin is wet.

## During servicing


- ∞ Keep hands, feet, and loose clothing away from moving parts on engine and generator.
- ∞ Keep the light tower and all its components clean.
- ∞ Keep labels legible. Replace damaged or missing labels. (Replacement labels are available from the factory.)
- ∞ When hoisting or loading the trailer:
  - Ensure devices such as slings, chains, hooks, ramps, and jacks are secure and will bear the weight of the trailer. The trailer's gross vehicle weight rating (GVWR) is displayed on the light tower vehicle identification tag.
  - Be aware and cautious of people's proximity to the trailer. Always ensure the safety of nearby people.

# Labels




Labels provide instructions and information. They also warn of hazards. For convenience and safety, keep all labels in legible condition, replacing labels when damaged or missing. Replacement labels are available from the factory.



Samples of labels and their descriptions are provided in Table 1.1.



**Figure 1.1 Label locations**





**Table 1.1 Label samples and descriptions**

No.	Label	Description	No.	Label	Description
A	1092 6814 00 	Decal : Electrical shock	C		Decal : Tyre Pressure
B	1092 6819 00 	Decal : Operation manual	D	1092 6805 00 	Decal : Towing instruction

No.	Label	Description	No.	Label	Description
E	1092 6829 00	Decal : High voltage	G		Decal : Flash
F	1092 6812 00	Decal : Light	H	1092 6813 00	Decal : Poison
					

No.	Label	Description	No.	Label	Description
I	<p>1094 2280 00</p> 	Decal : Danger electrical power line	K	<p>1079 9919 51</p> 	Decal: Rotation direction
J		Decal : Replace wire or winch	L	<p>1092 6822 00</p> 	Decal : Fan

No.	Label	Description	No.	Label	Description
M		Fork lift	O		Decal : Hot
N	1092 6806 00	Decal : Lifting hook	P	1092 6824 00	Decal : Grounding round



No.	Label	Description	No.	Label	Description
R		Decal : ATLAS COPCO black			
S		Decal : ATLAS COPCO white			

# Assembly

## Tow hitch

There are 3 options for tow hitch.

- Pintle hook
- 2-inch-ball
- Combo hitch for a 2-inch-ball and pintle hook

For combo hitch option only:

When the light tower ships from the factory, the tow bar is set up to use the lunette ring for towing by a vehicle with a pintle hook. To use a ball coupler, follow the procedure below.

To reverse the tow hitch:

1. Remove the two large bolts that hold the tow hitch to the draw bar.
2. Lift the hitch off the drawbar and rotate the hitch end-to-end.
3. Return the hitch to the draw bar, making sure to align the bolt holes.
4. Reinstall the bolts and tighten the nuts fully.

## Loose parts

During transportation, below parts would be disassembled.


- Drawbar with towing hitch
- Lifting jack
- Air outlet duct

Assemble loose parts before use

### Notice



Check and unload loose parts before unloading units from container.

- A - Drawbar with towing hitch ( option )
- B - Lifting jack
- C - Air outlet duct



# Light fixture wiring

## Light fixture numbering sequence



Coil cord wire connection	
Number wire	Connect to
51	T1
52&57	T2
53	T5
54	T6
56	T4
55	T3
58	T8
59	T7

Grounding wire connection		
Name wire	Connect to	Connect to
PE 1	N1	N2
PE 2	N1	T3

Lamp 1 wire connection	
Color wire	Connect to
Black	T1
White	T2
Green	T3

Lamp 2 wire connection	
Color wire	Connect to
Black	T5
White	T6
Green	T3

Lamp3 wire connection	
Color wire	Connect to
Black	T4
White	T2
Green	T3

Lamp 4 wire connection	
Color wire	Connect to
Black	T8
White	T7
Green	T3

# Operation

## Safety

Before operating the light tower, read and be familiar with this instruction manual.

Read and follow all safety instructions (see page 8).


### CAUTION

Do not run unit with door opened.

## Control panels

The light tower control panel comprises:

- Circuit breakers for engaging power
- An electrical receptacle for powering external equipment (Option)
- An hour meter to track engine use
- Key switch for starting and stopping the engine and a glow-plug indicator for the engine's start coil
- For engine operating instructions. (See page 25)
- Do not overload machine with socket. Turn off some lamps if you need more power



**Figure 3.1 A standard control panel.**

A - Main circuit breaker/power switch

B - Lamp circuit breakers/power switches

C - Electrical receptacle and breaker for external power (Option)

D - Engine key switch and glow-plug indicator.

E - Hour meter.

## Towing and hoisting

### Before towing

Before towing, prepare the light tower as follows.

1. Lower the light tower:
  - a Verify the light tower mast is in the down position and secured in place with the horizontal-lock pin .

- b If necessary, attach a red flag to the end of the mast.
2. Check tires, wheels, and lights:
    - a Check tires for wear. Replace worn tires.
    - b Verify tires are fully inflated to the proper pressure.
    - c Verify that all wheel lugs are in place and tightened. Do not tow the trailer if a wheel lug is missing.
    - d Ensure the trailer brake lights, taillights, and directional (turn) indicators are hooked up and functioning properly.
  3. Check the tow hitch and safety chains:
    - a Ensure the tow hitch and coupling on the tow vehicle are rated for weight equal to or greater than the trailer's gross vehicle weight rating (GVWR). The GVWR is displayed on the light tower vehicle identification tag.
    - b Inspect the tow hitch and coupling for wear and damage. Replace or repair if necessary.
    - c Verify the rear and side levelling jacks are in the up position, the outriggers are contracted, and all are secured with their locking pins.
    - d Use the drawbar-mounted jack to raise the front of the trailer and set the tow hitch on the tow vehicle. Ensure the tow hitch is properly engaged and locked.
    - e Raise, rotate, and lock the front jack in the up position.
    - f Verify approved safety chains are attached properly to both the trailer and tow vehicle.

## During towing

- Do not tow the trailer with any people, parts, supplies, or additional equipment attached to it or loaded onto it.
- Do not tow additional trailers or other equipment in tandem with the light tower trailer.
- The recommended maximum speed for highway towing is 45 MPH (72 km/h). For offroad towing, the recommended maximum speed is 10 MPH (16 km/h) or less, depending on terrain.
- Adhere to all applicable DOT regulations when towing the trailer.

## After towing

Release the trailer tow hitch from the tow vehicle as follows:

1. Locate the levelling jack on the trailer drawbar at the front of the trailer.
2. Pull the locking pin and rotate the jack downward. When the jack is properly set, the locking pin snaps into position with an audible “click.”
3. Block or chock the trailer wheels.
4. Release the tow hitch from the ball coupler or pintle on the tow vehicle.
5. Crank the jack handle until the jack foot touches the ground and the tow hitch rises up off the tow vehicle.
6. Move the tow vehicle away from the trailer.

## Hoisting


The light tower may be hoisted by means of the hoist ring or forklift slots mounted on the lifting beam.

(see Figure 3.2).

Prior to hoisting:

- Ensure the mast is in the lowest position.
- Return levelling jacks and outriggers to the travel position, and ensure they are all secured in place with their locking pins.

Figure 3.2 Hoisting ring and forklift slots



## Location

- To achieve the best possible light coverage, locate the light tower on the same level as the area to be lighted, or higher.
- To reduce the risk of personal injury, ensure the surrounding area is in good order and free of debris.
- To reduce the risk of shifting, rolling, or overturning, locate the light tower on a firm, level surface, with enough space to deploy the trailer's outriggers.
- Ensure convenient access to earth ground.
- The light tower mast can be extended to 24.5 feet (7.5 meters) in height. Ensure the area above the trailer is clear of obstructions.



### DANGER



**Electric shock hazard.**

**Contact with overhead electrical power lines will cause serious injury or death.**

Do not position light tower under power lines.

# Deployment

## Levelling the trailer

Prior to raising and extending the light tower mast, the trailer must be level and the outriggers extended for increased stability

### **WARNING**

**Falling equipment could cause serious injury or death.**

- Level the trailer and extend outriggers prior to use.
- For safe operation, outriggers must remain extended while the tower mast is vertical.

To level the trailer:

1. Locate the levelling jack on the trailer drawbar at the front of the trailer.
2. Pull the locking pin and rotate the jack downward. When the jack is properly set, the locking pin snaps into position with an audible “click.”
3. Block or chock the trailer wheels.
4. Release the tow hitch from the ball coupler or pintle on the tow vehicle.
5. Crank the jack handle until the jack foot touches the ground and the tow hitch rises up off the tow vehicle.
6. Locate the outrigger on either side of the trailer. Pull the outrigger locking pin (not the jack locking pin) and pull the outrigger outward, away from the trailer, as far as it will go. When fully extended,

the locking pin snaps into position with an audible “click.”

7. Pull the jack locking pin and rotate the jack downward until the locking pin engages. Do not lower the jack foot yet.
8. Repeat the previous two steps for the other outrigger, then locate and set the jack at the rear of the trailer.
9. Determine which side of the trailer is highest, and extend the jack foot on that side downward until it rests firmly on the ground. Then level the trailer with the remaining three jacks.
10. Use leveler for leveling the machine.

## Raising the tower

When the tower is vertical, the mast can be extended to 24.5 feet (7.5 meters). The tower can be rotated 360 degrees left or right while the mast is extended and the lights are lit.

To raise the tower and aim the lights, use the following instructions.

1. Before raising the tower:
  - a Adjust the light fixtures to point upward or downward, and inward or outward.
    - The lights can be positioned without tools.
    - To aim the lights, loosen the knob on the outside end of each fixture, and use the integrated handles to move the fixture. Tighten the knob when done.
  - b Ensure the trailer wheels are blocked or chocked.
  - c Level the trailer and extend the outriggers.

- d Connect the trailer ground stud to earth ground (see Figure 3.3).
- e Take the weather into account: do not raise or use the tower in high winds or an electrical storm. The tower can afford 80 km/h wind load.
- f Ensure the area above the tower is clear of all obstructions.
- g Stop raising tower when you see "STOP" on mast

### **DANGER**

**Electric shock hazard.**  
**Contact with overhead electrical power lines will cause serious injury or death.**

Do not position light tower under power lines.




Figure 3.3 Ground stud

2. To raise the tower, see Figure 3.5 and follow these instructions:
- a Remove the horizontal-lock pin from the transport cradle.
  - b Rotate the handle of the drawbar-mounted winch to tighten the cable and raise the light tower mast.




Figure 3.5 Raising the tower

## Lowering the tower

Before moving or storing the light tower, lower the mast and lock it in place. To lower the tower, see Figure 3.6 and use the following instructions.

1. Turn off the tower lights and the engine. For increased lamp life, allow the lights to cool for 15 minutes before proceeding.
2. Rotate the mast:
  - a Loosen the rotation-lock knob.
  - b Use the handle on the mast to rotate the mast until the mast-mounted winch is on the same side of the mast as the trailer tow hitch.
  - c Tighten the rotation-lock knob.
3. Lower the tower:
  - Rotate the mast-mounted winch handle to lower the tower until the lights are down as far as possible.
  - While lowering the mast, ensure the power cord on the mast collapses freely and does not become pinched or tangled.




Figure 3.6 Lowering the tower

# Engine operation

## Starting the engine

1. Before starting the engine:
  - a Observe all engine safety precautions in page 8.
  - b Check engine oil, fuel, and coolant levels. Use only diesel fuel.
  - c If the fuel tank was drained or run dry, it might be necessary to prime the fuel lines. Refer to the engine manual for instructions.
  - d Ensure all circuit breakers on the light tower control panel are in the OFF position.


### CAUTION

#### Starting the engine under load will damage the light tower.

Before starting the engine, ensure all power switches (circuit breakers) are in the OFF position.

2. To start the engine:
  - a Insert the engine key into the key slot and turn the key one click clockwise. control panel (see Figure 3.7).
  - b The glow-plug indicator will remain lit until the engine's start coil reaches a predetermined temperature.
    - Do not start the engine while this indicator is lit.
    - Crank the engine immediately after the indicator light goes out.

3. When the glow-plug indicator light goes out, turn and hold the key at the START position.
4. Release the key as soon as the engine starts, or after 10 seconds if the engine does not start.



**Figure 3.7 Key slot and glow-plug indicator on main control panel**

### CAUTION

#### The engine can overheat and damage the start motor.

- Do not hold the engine key at the START position longer than 10 seconds, regardless of whether the engine starts.
  - After 10 seconds, return the key to the OFF position and wait 15 to 30 seconds before attempting to start the engine.
- 
- If the engine does not gain sufficient oil pressure within 30 seconds of starting, the automatic shutdown system will engage.
  - Allow the engine to warm up before engaging power to the lights or an external device connected to the power receptacle.

## Stopping the engine

To stop the engine:

1. Shut down power to lights and external devices plugged into the power receptacle.

### CAUTION

**Shutting down the engine before disengaging power could damage the ballasts and generator.**

Shut down power to all lights and the power receptacle before shutting down the engine.

2. Turn the engine key to the OFF position.

## Automatic engine shutdown

The power system is equipped with an automatic shutdown feature. This system prevents damage by shutting down the engine when oil pressure is too low or engine temperature is too high.

To restart the engine after an automatic shutdown has occurred, return the engine key to the OFF position, then follow the procedures above for starting the engine.


## Lights

### Turning the lights on

To turn on the lights, first toggle the main circuit breaker to ON (see Figure 3.8), then toggle the individual circuit breakers for each light one at a time.

- Metal halide lamps require a warm-up time of 5 to 15 minutes before reaching full brightness.

- After the metal halide lamps are turned off, they will not turn on again until they are cool. The lamps can take up to 15 minutes to cool.



**Figure 3.8 Circuit breakers/power switch**

### Turning the lights off

For increased lamp life, turn off lights and let the metal halide lamps cool 15 minutes before lowering the tower and moving the trailer.

After the metal halide lamps are turned off, they will not turn on again until they are cool. The lamps can take up to 15 minutes to cool.

### Degraded lamps

Degraded metal halide lamps may be difficult to light, and may shut off unpredictably after starting.

Degraded metal halide lamps should be replaced.

## Lamps that will not turn on

If the lamps do not light when power is applied, ensure the appropriate circuit breakers are set in the ON position. If the circuit breakers are on, and the lights are not visibly lighted within 5 minutes, follow these steps:

1. Switch all circuit breakers OFF. If any of the lights were lit, allow the lights to cool for 15 minutes before proceeding.
2. Lower the mast.
3. Ensure the lamps are cool.

### CAUTION

**Risk of severe burn.**

Before handling lights, allow lights to cool for 15 minutes.




4. Check that all lamps are tightened securely into their sockets.
5. Check for, and replace, burned out metal halide lamps.

## Lamp replacement


For lamp replacement instructions. (See page 30)

## Floodlight lux level - HiLight V5+




Case	Angle	Lamp 1	Lamp 2	Lamp 3	Lamp 4
1	<b>Inclination</b>	80	80	70	70
	<b>Rotation</b>	0	0	-25	+25
2	<b>Inclination</b>	80	80	70	70
	<b>Rotation</b>	+10	-10	-20	+20
3	<b>Inclination</b>	80-70	80-70	80-70	80-70
	<b>Rotation</b>	0	-180	-90	+90
4	<b>Inclination</b>	80	80	70	70
	<b>Rotation</b>	-20	-20	-60	+60

Case 1



Average Lux: 23  
4000 m<sup>2</sup>

Case 2




Average Lux: 23  
3600 m<sup>2</sup>

Case 3




Average Lux: 20  
5000 m<sup>2</sup>

Case 4



Average Lux: 33  
2500 m<sup>2</sup>

Lux level:



# Maintenance

## Daily inspection

When the light tower is in regular use, the following items should be checked daily:

- Check fluid levels and look for leaks.
- Inspect all exposed wiring for damage, worn insulation, and cuts.
- Inspect winch cables for wear and damage.

Repair or replace worn and damaged components immediately. Never use any equipment that is damaged or in need of repair.

### DANGER




**High voltage.**  
**Contact with live electrical circuits will cause severe injury or death.**

- Turn off power before servicing any component on the light tower.

## Lamp replacement

To replace a light bulb (lamp), refer to Figure 4.1 and follow the instructions below.



**Figure 4.1** Lamp assembly

1. To remove a lamp:
  - a Turn off power to all lamps and the control panel receptacle.
  - b Shut down the engine and allow the lamps to cool for 15 minutes.

### CAUTION

**Risk of severe burn.**

Before handling lights, allow lights to cool for 15 minutes.



- c Remove the screws securing the flange rings and remove the flange rings.
  - d Remove the protective lamp cover with the gasket attached.
  - e Remove the hardware securing one side of the lamp stabilizer. Once removed, swing the stabilizer to the side and unscrew the lamp.
2. To install a lamp:

### IMPORTANT!

Lamps will last longer if they are free of contaminants. To protect a new lamp from the natural oils on the fingertips, handle the lamp with cotton gloves or a clean, soft cloth.

- a Insert the lamp into the socket and secure it with the lamp stabilizer.
- b Ensure the gasket is fastened properly around the lamp cover.
- c Secure the cover to the reflector with the flange ring and screws.

## Servicing the engine

For engine-related maintenance and servicing, see the engine instruction manual.

## Replacement parts

For replacement parts, see the parts manual, document 9829 3827 01.

## Wiring diagrams



### DANGER

High voltage.

Contact with live electrical circuits will cause severe injury or death.

- Turn off power before servicing any component on the light tower.
- Only a qualified electrician should service the light tower electrical system.


## Lamp Positioning

### Transport mode

- Horizontal position


### Tilting

- Release the safety screw
- Rotate the lamps as per your desired position



# Circuit diagram - 9829 3552 00-01

Applicable for HiLight V4, HiLight V5+, engine circuit




## Legend 1

Wire size :	Colour code :
a = 1 mm <sup>2</sup>	0 = black
b = 1,5mm <sup>2</sup>	1 = brown
c = 2,5mm <sup>2</sup>	2 = red
d = 4 mm <sup>2</sup>	3 = orange
e = 6 mm <sup>2</sup>	4 = yellow
f = 10 mm <sup>2</sup>	5 = green
g = 16 mm <sup>2</sup>	6 = blue
h = 25 mm <sup>2</sup>	7 = purple
i = 35 mm <sup>2</sup>	8 = grey
j = 50 mm <sup>2</sup>	9 = white
	54= white/yellow

Mark	Grid	Name
S3	E6	Coolant temp. switch
S4	E6	Oil pressure switch
E1	F1	Preheat Resistor
GB1	F2	Battery 12Vdc
G2	F4	Charging Alternator
R1	E4	Regulator
K0	F3	Starter Relay
M1	F3	Starter Motor
M2	E6	Fuel pump
Y1	F5	Fuel stop solenoid
X1		Engine harness connector
(O)		Optional Equipment

Applicable for HiLight V4, engine control circuit



**Legend 1**

Wire size :	Colour code :
a = 1 mm	2 = black
b = 1,5mm	1 = brown
c = 2,5mm	2 = red
d = 4 mm	3 = orange
e = 6 mm	4 = yellow
f = 10 mm	5 = green
g = 16 mm	6 = blue
h = 25 mm	7 = purple
i = 35 mm	8 = grey
j = 50 mm	9 = white
	54= green/yellow


Mark	Grid	Name
S1	A7	Key Switch
S5	B5	Emergency stop
H0	E9	Preheat indicator
P1	F7	Hour meter
N1	E8	Preheat timer
N2	E7	Fuel stop solenoid timer
K1	D6	Relay
K2	C8	Relay
F1	B6	Fuse
X1		Engine harness connector
X4		Terminals
X7		Auxiliary terminals
(O)		Optional Equipment

**Notes.**

1. When emergency stop switch is applied, this wire shall be replaced by switch wire
2. For standard and CE cubicles, wires should comply with CE.




Applicable for HiLight V4, circuit 230V 50Hz



Ma	Gr id	Name
Q2	C1	Breaker 10A
Q3	C2	Breaker 10A
Q4	C3	Breaker 10A
Q5	C5	Breaker 10A
Q6	E6	Breaker 10A
B1-B4	D1-D5	Light ballast 230V 50HZ
C1-C4	E1-E5	Light capacity 480V, 30uf, 50Hz
H1-H4	F1-F5	Halogen lamp
X3		Terminals
X4		Terminals
X6	F6	Socket 10A
(O)		Option equipments


**Legend 1**

Wire size :	Colour code :
a = 1 mm	0 = black
b = 1.5mm	1 = brown
c = 2.5mm	2 = red
d = 4 mm	3 = orange
e = 6 mm	4 = yellow
f = 10 mm	5 = green
g = 16 mm	6 = blue
h = 25 mm	7 = purple
i = 35 mm	8 = grey
j = 50 mm	9 = white
	54 = green/yellow



- Notes,**
1. For standard and CE cubicles, wires should comply with CE.
  2. Only use for LC1003 MKII

Applicable for HiLight V4, HiLight V5+, AC power circuit 240/120V 60Hz





**Legend 1**

<u>Wire size :</u>	<u>Colour code :</u>
a = 1 mm <sup>2</sup>	0 = black
b = 1.5mm <sup>2</sup>	1 = brown
c = 2.5mm <sup>2</sup>	2 = red
d = 4 mm <sup>2</sup>	3 = orange
e = 6 mm <sup>2</sup>	4 = yellow
f = 10 mm <sup>2</sup>	5 = green
g = 16 mm <sup>2</sup>	6 = blue
h = 25 mm <sup>2</sup>	7 = purple
i = 35 mm <sup>2</sup>	8 = grey
j = 50 mm <sup>2</sup>	9 = white
	54= green/yellow

<u>Ma</u>	<u>Grid</u>	<u>Name</u>
G3	A4	Alternator 6KVA, 50Hz
Q1	G4	Main breaker 25A
X4		Terminals

- Notes,
1. For standard and CE cubicles, wires should comply with CE.
  2. This circuit for cubicle 1094052780,1094052880,1094062880,1094052881.

Applicable for HiLight V4, AC power circuit 120V 60Hz with Duplex socket or no socket or no socket with ELR or Duplex with ELR




**Legend 1**

Wire size :	Colour code :
a = 1 mm <sup>2</sup>	0 = black
b = 1.5mm <sup>2</sup>	1 = brown
c = 2.5mm <sup>2</sup>	2 = red
d = 4 mm <sup>2</sup>	3 = orange
e = 6 mm <sup>2</sup>	4 = yellow
f = 10 mm <sup>2</sup>	5 = green
g = 16 mm <sup>2</sup>	6 = blue
h = 25 mm <sup>2</sup>	7 = purple
i = 35 mm <sup>2</sup>	8 = grey
j = 50 mm <sup>2</sup>	9 = white
	54 = green/yellow

<u>Ma</u>	<u>Grid</u>	<u>Name</u>
G3	A4	Alternator
Q1	A4	Main breaker 50A
Q1.1	G4	Earth leakage breaker 30mA
F10	D2	Fuse 2A
F11	D2	Fuse 2A
X4		Terminals

Notes,  
 1. 1. Only for controller cubicle DSEL401 MKII  
 2. For standard and CE cubicles, wires should comply with CE.

Applicable for HiLight V4, HiLight V5+, lamp circuit 240/120V 60Hz



**Legend 1**


<b>Wire size:</b>	<b>Colour code:</b>
a = 1 mm <sup>2</sup>	0 = black
b = 1.5mm <sup>2</sup>	1 = brown
c = 2.5mm <sup>2</sup>	2 = red
d = 4 mm <sup>2</sup>	3 = orange
e = 6 mm <sup>2</sup>	4 = yellow
f = 10 mm <sup>2</sup>	5 = green
g = 16 mm <sup>2</sup>	6 = blue
h = 25 mm <sup>2</sup>	7 = purple
i = 35 mm <sup>2</sup>	8 = grey
j = 60 mm <sup>2</sup>	9 = white
	5# = green/yellow

Ma	Gr id	Name
Q2	C1	Breaker 16A
Q3	C2	Breaker 16A
Q4	C3	Breaker 16A
Q5	C5	Breaker 16A
Q6	E6	Breaker 20A
Q7	E7	Breaker 10A
B1-B4	D1-D5	Light ballast 120V 60Hz
C1-C4	E1-E5	Light capacity 480V, 25uf, 60hz
H1-H4	F1-F5	Halogen lamp
X6	F6	Socket 10A 240V
X7	E6	Socket 20A 120V
X3		Terminals
(O)		Option equipments

**Notes.**

1. For standard and CE cubicles, wires should comply with CE.
2. This circuit for cubicle 1094052780, 1094052880, 1094062880, 1094052881.

Applicable for HiLight V4, lamp circuit 120V 60Hz with Duplex or no socket




**Legend 1**

<b>Wire size :</b>	<b>Colour code :</b>
a = 1 mm	0 = black
b = 1.5mm	1 = brown
c = 2.5mm	2 = red
d = 4 mm	3 = orange
e = 6 mm	4 = yellow
f = 10 mm	5 = green
g = 16 mm	6 = blue
h = 25 mm	7 = purple
i = 35 mm	8 = grey
j = 50 mm	9 = white
	5L = green/yellow


<u>Ma</u>	<u>Grid</u>	<u>Name</u>
Q2	C1	Breaker 16A
Q3	C2	Breaker 16A
Q4	C3	Breaker 16A
Q5	C5	Breaker 16A
Q6	E6	Breaker 20A
B1-B4	D1-D6	Light ballast 120V 60Hz
C1-C4	E1-E5	Light capacity 480V, 24uf, 60Hz
H1-H4	F1-F5	Halogen lamp
X7	E6	Socket 20A 120V
X3		Terminals
(O)		Option equipments

- Notes,**
1. For standard and CE cubicles, wires should comply with CE.
  2. Only use for LC1003 MKII

Applicable for HiLight V4, HiLight V5+, E- winch circuit-12VDC



Applicable for HiLight V4, HiLight V5+, ECU engine circuit




**Legend**

<b>Wire size :</b>	<b>Colour code :</b>
a = 1 mm	0 = black
b = 1.5mm	1 = brown
c = 2.5mm	2 = red
d = 4 mm	3 = orange
e = 6 mm	4 = yellow
f = 10 mm	5 = green
g = 16 mm	6 = blue
h = 25 mm	7 = purple
i = 35 mm	8 = grey
j = 50 mm	9 = white
k = 70 mm	S4= green/yellow
l = 95 mm	
lx = 95 mm EPR-CSP (BS6195-4C)	
bx = 1.5mm NSGAF0eU	

<b>Mark</b>	<b>Grid</b>	<b>Name</b>
S3	E6	Coolant temp. switch
S4	E6	Oil pressure switch
E1	F1	Preheat Resistor
GB1	F2	Battery 12Vdc
G2	F4	Charging Alternator
R1	E4	Regulator
K0	F3	Starter Relay
M1	F3	Starter Motor
M2	E6	Fuel pump
Y1	F5	Fuel stop solenoid
X1		Engine harness connector
(O)		Optional Equipment



Applicable for HiLight V4, HiLight V5+, ECU control circuit



**Legend**


Wire size :	Colour code :
a = 1 mm	2 = 0 = black
b = 1.5mm	2 = 1 = brown
c = 2.5mm	2 = 2 = red
d = 4 mm	2 = 3 = orange
e = 6 mm	2 = 4 = yellow
f = 10 mm	2 = 5 = green
g = 16 mm	2 = 6 = blue
h = 25 mm	2 = 7 = purple
i = 35 mm	2 = 8 = grey
j = 50 mm	2 = 9 = white
k = 70 mm	2 = 54 = green/yellow
l = 95 mm	
lx = 95 mm EPR-CSP (BS6195-4C)	
bx = 1.5mm NSGAFOEU	

Mark	Grid	Name
N2		ECU
S10	E4	Water temp. sensor
B11	E5	Speed sensor
Y1	E6	Solenoid
X10		ECU connector
X11		Water temp. sensor connector
X12		Speed sensor connector
X13		Solenoid connector
(O)		Optional Equipment

Note1,  
50Hz, wire 96 connecting GND  
60Hz, wire 96 not connecting GND


Note1

Applicable for HiLight V4, HiLight V5+, AC power circuit 230V 50Hz for no socket or Weipu socket; 240V 60Hz for Weipu socket



Note1: Only for controller cubicle LC1003 MKII

Note 2: For standard and CE cubicles, wires comply with CE




(0)  
Earth leakage connection diagram  
230V - 50Hz  
240V - 60Hz

Legend

Wire size :	Colour code :
a = 1 mm <sup>2</sup>	0 = black
b = 1.5mm <sup>2</sup>	1 = brown
c = 2.5mm <sup>2</sup>	2 = red
d = 4 mm <sup>2</sup>	3 = orange
e = 6 mm <sup>2</sup>	4 = yellow
f = 10 mm <sup>2</sup>	5 = green
g = 16 mm <sup>2</sup>	6 = blue
h = 25 mm <sup>2</sup>	7 = purple
i = 35 mm <sup>2</sup>	8 = grey
j = 50 mm <sup>2</sup>	9 = white
k = 70 mm <sup>2</sup>	54 = green/y
l = 95 mm <sup>2</sup>	
lx = 95 mm <sup>2</sup>	EPR-CSP (BS6195
bx = 1.5mm <sup>2</sup>	NSGFF0eU)

Ma	Grid	Name
G3	A4	Alternator
Q1	G4	Main breaker 10A
Q1.1	G4	Earth leakage breaker 30mA
F10	D2	Fuse 2A
F11	D2	Fuse 2A
X4		Terminals
C1		Alternator capacitor

Applicable for HiLight V5+, AC power circuit 230V 50Hz for no socket or Weipu socket; 240V 60Hz for Weipu socket




Notes,  
 1. For standard and CE cubicles, wires should comply with CE.  
 2. Only use for LC1003 MKII

**Legend**

<b>Wire size :</b>	<b>Colour code :</b>
a = 1 mm <sup>2</sup>	0 = black
b = 1.5 mm <sup>2</sup>	1 = brown
c = 2.5 mm <sup>2</sup>	2 = red
d = 4 mm <sup>2</sup>	3 = orange
e = 6 mm <sup>2</sup>	4 = yellow
f = 10 mm <sup>2</sup>	5 = green
g = 16 mm <sup>2</sup>	6 = blue
h = 25 mm <sup>2</sup>	7 = purple
i = 35 mm <sup>2</sup>	8 = grey
j = 50 mm <sup>2</sup>	9 = white
k = 70 mm <sup>2</sup>	54 = green/y
l = 95 mm <sup>2</sup>	
lx = 95 mm <sup>2</sup> EPR-CSP (BS6195-4C)	
bx = 1.5mm NSGFF0eU	

Ma	Gr id	Name
Q2	C1	Breaker 6A
Q3	C2	Breaker 6A
Q4	C3	Breaker 6A
Q5	C5	Breaker 6A
Q6	E6	Breaker 10A
H1-H4	F1-F5	LED AC
X3		Terminals
X4		Terminals
X6	F6	Socket 10A
(O)		Option equipments

Applicable for HiLight V4, HiLight V5+, AC power circuit 120V 60Hz for no socket or Duplex socket




**Legend**

Wire size	Colour code
a = 1 mm <sup>2</sup>	0 = black
b = 1.5mm <sup>2</sup>	1 = brown
c = 2.5mm <sup>2</sup>	2 = red
d = 4 mm <sup>2</sup>	3 = orange
e = 6 mm <sup>2</sup>	4 = yellow
f = 10 mm <sup>2</sup>	5 = green
g = 16 mm <sup>2</sup>	6 = blue
h = 25 mm <sup>2</sup>	7 = purple
i = 35 mm <sup>2</sup>	8 = grey
j = 50 mm <sup>2</sup>	9 = white
k = 70 mm <sup>2</sup>	54 = green/y
l = 95 mm <sup>2</sup>	
lx = 95 mm <sup>2</sup> EPR-CSP (BSG195)	
bx = 1.5mm <sup>2</sup> NSGFF0eU	

Ma	Grid	Name
G3	A4	Alternator
Q1	G4	Main breaker 20A
Q1.1	G4	Earth leakage breaker 30mA
F10	D2	Fuse 2A
F11	D2	Fuse 2A
X4		Terminals
C1		Alternator capacitor

Applicable for HiLight V5+, AC lamp circuit 120V 60Hz for Duplex socket



Notes,


1. For standard and CE cubicles, wires should comply with CE.

⚠ 2. Only use for LC1003 MKII

Legend

<b>Wire size :</b>	<b>Colour code :</b>
a = 1 mm <sup>2</sup>	0 = black
b = 1.5mm <sup>2</sup>	1 = brown
c = 2.5mm <sup>2</sup>	2 = red
d = 4 mm <sup>2</sup>	3 = orange
e = 6 mm <sup>2</sup>	4 = yellow
f = 10 mm <sup>2</sup>	5 = green
g = 16 mm <sup>2</sup>	6 = blue
h = 25 mm <sup>2</sup>	7 = purple
i = 35 mm <sup>2</sup>	8 = grey
j = 50 mm <sup>2</sup>	9 = white
k = 70 mm <sup>2</sup>	54 = green/y
l = 95 mm <sup>2</sup>	
lx = 95 mm <sup>2</sup>	EPR-CSP (BS6195
bx = 1.5mm <sup>2</sup>	NSGRFOeU

Ma	Gr id	Name
Q2	C1	Breaker 6A
Q3	C2	Breaker 6A
Q4	C3	Breaker 6A
Q5	C5	Breaker 6A
Q7	E6	Breaker 20A
H1-H4	F1-F5	LED AC
X3		Terminals
X4		Terminals
X7	F6	Socket 20A
(O)		Option equipments



Duplex socket (option)

Applicable for HiLight V4, engine circuit

**Legend 1**


Wire size:	Colour code:
a = 1 mm	0 = black
b = 1,5 mm	1 = brown
c = 2,5 mm	2 = red
d = 4 mm	3 = orange
e = 5 mm	4 = yellow
f = 10 mm	5 = green
g = 16 mm	6 = blue
h = 25 mm	7 = purple
i = 35 mm	8 = grey
j = 50 mm	9 = white
k = 70 mm	54 = green/yellow
l = 95 mm	
lx = 95 mm	EPR-CSP (8S6195-4C)
lx = 1,5 mm	N58AFC01

Ma	Grid	Nam
A1	C6	Controller DSE L401
F1	F3	Fuse 30A
F2	F3	Fuse 5A
F3	E4	Fuse 10A
F4	E4	Fuse 15A
K1	C7	Relay
K2	C8	Relay
K3	C8	Relay
K4	C8	Relay
K10	E6	Relay
K11	E6	Relay
K12	E7	Relay
K13	E7	Relay
K100	E6	Relay
H0	F2	Preheat indicator
P1	C10	Photocell relay
P1.1	C10	Photocell sensor
S5	E6	Emergency stop switch
S10	A4	REMOTE/OFF/ION switch
X1	G2	Connector
N2	E5	Solenoid timer
X4	E3	Terminal

Symbol	S20	1-2	5-6	7-8
	REMOTE			
0	OFF			
1	ON			

Notes.

1. For standard and CE cubicles, wires should comply with CE
2. Other circuit refer to 9829355200 except 9829355200-02



Applicable for HILight V5+, engine circuit


**Legend**

<b>Wire size:</b>	<b>Colour code:</b>
a = 1 mm	0 = black
b = 1,5mm	1 = brown
c = 2,5mm	2 = red
d = 4 mm	3 = orange
e = 6 mm	4 = yellow
f = 10 mm	5 = green
g = 16 mm	6 = blue
h = 25 mm	7 = purple
i = 35 mm	8 = grey
j = 50 mm	9 = white
k = 70 mm	54 = green/yellow
l = 95 mm	
lx = 95 mm EPR-CSP (BS6196-4C)	
bx = 1,5mm NSGAFOeU	

Ma	Grid	Item
A1	C6	Controller DSE L401
F1	F3	Fuse 30A
F2	F3	Fuse 10A
F3	F3	Fuse 10A
F4	F3	Fuse 5A
F5	F3	Fuse 5A
K1	C7	Relay
K2	C8	Relay
K3	C8	Relay
K4	C8	Relay
K10	E6	Relay
K11	E6	Relay
K12	E7	Relay
K13	E7	Relay
K100	E6	Relay
H0	F2	Preheat indicator
P1	C10	Photoac relay
P1,1	C10	Photoac sensor
S5	E6	Emergency stop switch
S10	A4	REMOTE/OFF/ION switch
X1	G2	Connector
N2	E5	Solenoid limiter
X4	E3	Terminal




Symbol	S20	1-2	5-6	7-8
	REMOTE			
0	OFF			
1	ON			



**Notes,**

1. For standard and CE cubicles, wires should be comply with CE
2. Other circuit refer to 9829355250 except 9829355250-02


Applicable for HiLight V4, control circuit



Notes.  
 1. When emergency stop switch is applied, this wire shall be replaced by switch wire  
 2. Engine control circuit refer to 9829355200-01.  
 3. All wires comply with CSA.

Applicable for HiLight V4, AC power circuit 120/240V 60Hz

G3 120/240V - 60Hz



Legend 1

<u>Wire size :</u>	<u>Colour code :</u>
a = AWG16	0 = black
b = AWG14	1 = brown
c = AWG12	2 = red
d = AWG10	3 = orange
e = AWG8	4 = yellow
f = AWG6	5 = green
g = AWG4	6 = blue
h = AWG2	7 = purple
i = AWG0	8 = grey
j = AWG00	9 = white
	54 = green/yellow

<u>Ma</u>	<u>Gr id</u>	<u>Name</u>
G3	A4	Alternator
Q1	D4	Main breaker 25A
X4		Terminals
F10	D4	Fuse
F11	D4	Fuse

Notes,  
 1. Only for controller cubicle LC1003 MK11  
 2. All wires comply with CSA.


Applicable for HiLight V4, lamp circuit 120/240V 60Hz  
 With Longxin coil cord, wire color 51 and 53 are black; 56 and 58 are red; 52,54,57 and 59 are white; 55 is green/yellow;  
 or with Philatron coil cord, wire color 51 is red; 53 is black; 56 is brown; 58 is orange; 52 is blue; 54 is yellow; 57 is purple; 59 is white; 55 is green.



**Legend 1**


<b>Wire size :</b>	<b>Colour code :</b>
a = AWG16	0 = black
b = AWG14	1 = brown
c = AWG12	2 = red
d = AWG10	3 = orange
e = AWG8	4 = yellow
f = AWG6	5 = green
g = AWG4	6 = blue
h = AWG2	7 = purple
i = AWG0	8 = grey
j = AWG00	9 = white
	54= green/yellow

<u>Ma</u>	<u>Gr id</u>	<u>Name</u>
Q2	C1	Breaker 16A
Q3	C2	Breaker 16A
Q4	C3	Breaker 16A
Q5	C5	Breaker 16A
Q6	E6	Breaker 20A
Q7	E7	Breaker 20A
B1-B4	D1-D5	Light ballast 120V 60HZ
C1-C4	E1-E5	Light capacity 480V, 24uf, 60Hz
H1-H4	F1-F5	MIH lamp
X6	F6	Socket 20A 120V
X7	F7	Socket 20A 120V
X9	F8	Socket 30A 240V
X3		Terminals
X5		Terminals
(O)		Option equipments



Notes,  
 1. All wires comply with CSA.

Applicable for HILight V5+, ECU control circuit



S1

Preheat	○	○	○		
Off	○				
On	○	○			
Start	○	○	○	○	
	B(30)	BR(AC)	R1(19)	C(17)	R2(50)


Legend 1

Wire size :	Colour code :
a = AWG16	0 = black
b = AWG14	1 = brown
c = AWG12	2 = red
d = AWG10	3 = orange
e = AWG8	4 = yellow
f = AWG6	5 = green
g = AWG4	6 = blue
h = AWG2	7 = purple
i = AWG0	8 = grey
j = AWG00	9 = white
	54 = green/yellow

Mark	Grid	Name
S1	A6	Key Switch
S5	A5	Emergency stop
H0	E9	Preheat indicator
H5	F2	Warning indicator
P1	F7	Hour meter
N1	E8	Preheat timer
K1	D6	Relay
K2	D8	Relay
F1	B2	Fuse
F2	E2	Fuse
F3	E2	Fuse
F4	F2	Fuse
X1		Engine harness connector
X4		Terminals
X7		Auxiliary terminals
(O)		Optional Equipment

- Notes,
1. When emergency stop switch is applied, this wire shall be replaced with switch wire
  2. Control circuit see page 9829355250-01,9829355250-03
  3. All wires comply with CSA

Applicable for V5+, AC power circuit 120/240V 60Hz



Note1


### Legend 1

Wire size :	Colour code :
a = AWG16	0 = black
b = AWG14	1 = brown
c = AWG12	2 = red
d = AWG10	3 = orange
e = AWG8	4 = yellow
f = AWG6	5 = green
g = AWG4	6 = blue
h = AWG2	7 = purple
i = AWG0	8 = grey
j = AWG00	9 = white
	54= green/yellow

Ma	Gr 1 d	Name
G3	A4	Alternator
Q1	F2	Main breaker 10A
X3		Terminals
X4		Terminals
C1		Alternator capacitor

Notes,  
 1, Only for controller cubicle LC1003 MKII  
 2, All wires comply with CSA.


Applicable for HiLight V5+, LED circuit 120V 60Hz only  
 With Longxin coil cord, wire color 51 and 53 are black; 56 and 58 are red; 52,54,57 and 59 are white; 55 is green/yellow;  
 or with Philatron coil cord, wire color 51 is red; 53 is black; 56 is brown; 58 is orange; 52 is blue; 54 is yellow; 57 is purple; 59 is white; 55 is green.



**Legend 1**

<b>Wire size :</b>	<b>Colour code :</b>
a = AWG18	0 = black
b = AWG14	1 = brown
c = AWG12	2 = red
d = AWG10	3 = orange
e = AWG8	4 = yellow
f = AWG6	5 = green
g = AWG4	6 = blue
h = AWG2	7 = purple
i = AWG0	8 = gray
j = AWG00	9 = white
	56= green/yellow


Ma	Gr id	Name
Q2	C1	Breaker GA
Q3	C2	Breaker GA
Q4	C3	Breaker GA
Q5	C5	Breaker GA
Q7	E6	Breaker 20A
H1-H4	F1-F5	LED AC
X7	F6	Socket 120V/20A
X3		Terminals
X4		Terminals
(O)		Option equipments



Notes:  
 1. All wires comply with CSA.

# Axle maintenance manual

## Axle



## Safety Precautions

- Welding or drilling on shaft tube is not allowed.
- Select the matching wheel hub: wheel offset, PCD (bolt circle), tire bolt hole diameter, with the angle must be connected with the hub and the wheel bolts to match. Pay particular attention to the recommended tightening torque.

## Maintenance

After 10,000 km or 3 years (whichever is earlier):

- Check the wheel bearing axial clearance and adjust, if necessary.
- Check the quality and quantity of grease and replace if necessary.

## Operation

### Check the axle wheel bearing axial clearance:

Steps:

- Jacking trailer, check whether the wheels turn smoothly, without hindrance.
- Axial flipping tires, whether we can feel the obvious gap

### Re-adjust the axle hub bearing axial clearance:

Steps:

- Remove the wheels and wheel covers.
- Remove the slotted nut cotter pin.
- Tighten shaft nut, then back to loose 1/2 turn (180 °), then tighten 1/4 turn (90 °).

- Check the wheel functioning - is free to rotate, and the wheel can not be detected with axial clearance.
- Plug cotter pin.

**Note:** Adjust the bearing correctly. Over tightening may result in bearing damage.

- Check the quality and quantity of grease. If necessary, fill or replace the grease.  
Wheel Bearing Grease: 2 # of lithium grease.
- Replace the wheel hub cover.

## Wheel bolt tightening torque

Thread Size	Hexagon square width	Tightening torque Nm
M12X1.5	SW19	90

## U-bolt nut tightening torque

Thread Size	Hexagon square width	Tightening torque Nm
M12X1.5	SW18	90


# Setting the Lc1003™ controller



Controller settings should only be performed by a qualified technician.

## Push button and LED functions

Following push buttons are used on the Lc1003™:



1



**STOP:** Is used to activate Stop/Reset mode. When pressing the STOP button, the generator will unload (Light Output 1, 2, 3 & 4 becomes inactive (if used)), the fuel supply de-energises and the engine shuts down. Pressing the STOP button will also clear any alarm conditions for which the triggering criteria have been removed.

2



**AUTO:** Is used to activate Auto mode. It is also used for floodlight operation:

- switch on the floodlights manually (S20: ON)
- switch on/off the floodlights automatically, in REMOTE mode (S20: REMOTE)

3



**START:** Is used to start the unit in Manual mode. It is also used to switch off the floodlights manually (S20: ON).

4



**UP:** Is used for navigating the instrumentation, event log and configuration screens and to go to the previous parameter level.

5



**DOWN:** Is used for navigating the instrumentation, event log and configuration screens and to go to the next parameter level.

Following LEDs are used on the Lc1003™:



1

**Stop**

LED indicates that the unit is in Stop/Reset Mode.

2

**Auto**

LED indicates that the unit is in Auto Mode.

3


**Start**

LED indicates that the unit is in Manual/Start Mode.

## Module display

### Home page

The home page is the page displayed when no other page has been selected:



- 1 Instrumentation icon
- 2 Active configuration
- 3 FPE/Auto run
- 4 Light output icons
- 5 Alarm icon
- 6 Mode icon
- 7 Instrumentation and Unit e.g. voltage reading

## Icon overview

### Instrumentation icons

Display	Description
	The default home page which displays Generator voltage and the Auto Run icon
	Generator voltage and frequency instrumentation screen
	Current and load instrumentation screen
	Engine speed instrumentation screen
	Hours run instrumentation screen
	Battery voltage instrumentation screen
	Oil pressure instrumentation screen
	Coolant temperature instrumentation screen
	Fuel sender instrumentation screen

Display	Description
	Appears when the event log is being displayed
	Current time held in the unit
	The current value of the scheduler run time and duration
	ECU diagnostic trouble codes
	Oil Filter maintenance timers
	Air Filter maintenance timers
	Fuel Filter maintenance timers

### Active configuration

Display	Description
	Appears when the main configuration is selected.
	Appears when the alternative configuration is selected.

## Front panel editor (FPE) / Auto Run icons

Display	Description
	Appears when a remote start input is active
	Appears when a low battery run is active
	Appears when a scheduled run is active

## Mode icons

Display	Description
	Appears when the engine is at rest and the unit is in stop mode.
	Appears when the engine is at rest and the unit is in auto mode.
	Appears when the engine is at rest and the unit is waiting for a manual start.
	Appears when a timer is active, for example cranking time, crank rest etc.
	Appears when the engine is running, and all timers have expired, either on or off load. The animation speed is reduced when running in idle mode.

Display	Description
	Appears when the unit is in the front panel editor.
	Appears when a USB connection is made to the controller.
	Appears if either the configuration file or engine file becomes corrupted.

## Light output icons

Display	Description
	Appears when the corresponding light output has been configured and is not active.
	Appears when the corresponding light output has been configured and is active.
	Appears when a timer to delay the light output activating or deactivating is in progress

## Alarm icons

To indicate the alarm that is currently active on the controller, an icon is displayed in the Alarm Icon section.

## Navigation menu

To enter the navigation menu, press both the UP and DOWN buttons simultaneously.

To navigate to the desired page, select the corresponding icon by pressing the UP and DOWN button and press the AUTO (Accept) button to enter.

If the AUTO button is not pressed, the display automatically returns to the home page.




Display	Description
	Home and generator voltage and frequency instrumentation
	Generator current and load instrumentation
	Engine instrumentation
	Module information
	Engine DTCs (Diagnostic Trouble Codes) if active

Display	Description
	Event Log

### Event log

The Lc1003™ module's event log contains a list of the last 15 record electrical trip or shutdown events and the engine hours at which they occurred.

Once the log is full, any subsequent electrical trip or shutdown alarms over writes the oldest entry in the log. Hence, the log always contains the most recent shutdown alarms. The module logs the alarm, along with the engine running hours.



- 1 Icon to indicate that the event log is currently displayed
- 2 Number of event displayed out
- 3 Light output status
- 4 The engine hours at which the event occurred
- 5 Icon to indicate the electrical trip or shutdown alarm that has been recorded
- 6 Current operating state of the module

To view the event log:


1. Press the UP and DOWN buttons simultaneously to display the navigation menu.
2. Once entered, cycle to the event log section (1) and enter.
3. To view the event log, repeatedly press the UP or DOWN buttons until the LCD screen displays the desired event.
4. Continuing to press the UP or DOWN buttons will cycle through the past alarms.
5. To exit the event log, press the UP and DOWN buttons simultaneously.

### Setting the Lc1003™ clock and timer

The Lc1003™ controller provides a basic scheduler that allows the operator to set a detailed time schedule following which the igniting of the floodlights can be programmed.

To set the Lc1003™ timer, follow the flow on the next page.

## Menu flow



Configuration Parameters – Scheduler		
901	Enable Scheduler	On (1), Off (0)
902	Schedule Run On or Off Load	On (1), Off (0)
903	Schedule Period	Weekly (0), Monthly (1)
904	Scheduler (1) Start Time	0:00:00
905	Scheduler (1) Start Day	0 (1=Monday)
906	Scheduler (1) Start Week	1,2,3,4
907	Scheduler (1) Duration	0:00:00
908	Scheduler (2) Start Time	0:00:00
...		
935	Scheduler (8) Duration	0:00:00

Configuration Parameters – Clock		
1001	Time of Day	0:00:00
1002	Day of Month	00
1003	Month of Year	00
1004	Year	0000

## Setting the Lc1003™ clock

1. Enter the weekly timer menu by pressing the STOP and AUTO button simultaneously.

The Operator and Service icon appear on the display.

2. To toggle between both icons, press the START (+) and STOP (-) button.
3. When the Operator icon lights up, press the AUTO button.

The scheduler parameter list appears on the display.

4. Scroll through the parameter list by pressing the UP/DOWN button, till parameter **1001** (Time of Day) is highlighted.
5. Press the AUTO (Accept) button to enter the parameter.
6. Scroll through the parameter values by pressing the START (+) and STOP (-) button.
7. When the desired value is reached, press the AUTO (Accept) button.

After setting a parameter, the parameter list appears again on the display.

8. Set parameters **1002**, **1003** and **1004** following the same procedure.
9. To exit the parameter list, press the AUTO button for three seconds.

## Setting the Lc1003™ timer

1. Enter the weekly timer menu as described above.
2. Select following parameters and settings to enable/set up the timer:

**901** Enable scheduler: ON

**902** Schedule run On or Off load: ON

3. To program the settings for Event 1, proceed as follows:

**903** Schedule period

- 0 = Weekly: Event 1 repeats every week
  - 1 = Monthly: Event 1 repeats every month
- Suggested: Weekly (0)

**904** Scheduler start time period

Set the desired time period. Therefore, the Lc1003™ clock should be set first.

**905** Scheduler start day

- 1 = Monday
- 2 = Tuesday
- ...

For one Event only one week day can be selected. To set several week days, more Events should be programmed.

**906** Scheduler start week

- 1 = monthly week 1
- 2 = monthly week 2
- ...

If for parameter 903 “week” schedule “0” has been selected, parameter 906 is set by default “monthly week 1”.

**907** Scheduler duration


Set the desired time period. When this value is set, Event 1 is closed.

4. To program the next event (Event 2), select and program parameter **908**. Continue with parameters **909**, **910** and **911** to complete Event 2.
5. Following this procedure up to 8 events can be programmed, e.g. 1 event per week day.
6. To exit the parameter list, press the AUTO button for three seconds.
7. To enable the weekly timer, put switch S20 to remote mode and push the AUTO button on the controller.

## Setting the sensitivity regulator

The photocell sensitivity regulator is used for regulating the luminosity sensitivity level of the photocell.

When the red LED (1) on the regulator is blinking, the regulator is reading the luminosity level measured by the photocell.



There are 2 blinking levels:

- Level 1: slow blinking

The photocell detects there is enough light, according to its set sensitivity level.

- Level 2: fast blinking

The photocell detects there is a prolonged luminosity change that falls below the set sensitivity level. Remote start will be triggered and the floodlights of the light tower will switch on automatically (if Remote start and Auto mode are selected, see also chapter “Operating the light tower” on page26).

The recommended value to set the regulator is at 50 Lux.

- < 50 Lux: the floodlights switch on.
- > 50 Lux: the floodlights switch off.


The luminosity level can be adjusted to a desired higher/lower level, according to the specific operating conditions of the light tower.

## ASM (Auto Rise and Lower Safety Mast)

The ASM option provides the possibility to not only switch on/off the floodlights automatically, but also to extend/lower the mast automatically.



**Before activating the ASM option, make sure that the lighting tower is properly positioned, away from overhead power cables or other obstructions.**



# Maintenance

## Maintenance schedule



Before carrying out any maintenance activity, check that the ignition switch is in position OFF and that no electrical power is present on the terminals.

Service PAK	Notes	Daily	Every 200 hrs	Every 400 hrs	Every 800 hrs
Service Pak HiLight V4	-	-	3002 6076 10	3002 6076 20	3002 6076 30
Service Pak HiLight V5+	-	-	3002 6078 40	3002 6078 50	3002 6078 60
<i>for the most important sub-assemblies, Atlas Copco has developed service kits that combine all wear parts. These service kits offer you the benefits of genuine parts, save on administration costs and are offered at reduces price, compared to the loose components. Refer to the parts list for more information on the contents of the service kit.</i>					
<b>Maintenance schedule (running hrs)</b>	Notes	Daily	Every 200 hrs	Every 400 hrs	Every 800 hrs
Empty air filter vacuator valves		x			
Check engine oil level (if necessary top up)		x			
Check coolant level	(4)	x			
Check/Fill fuel level	(3)	x			
Check air intake vacuum indicators		x			
Check for leaks in engine-, compressor-, air-, oil-, or fuel system			x	x	x
Check function of coolant heater (option)					x
Check on abnormal noise		x			
Check electrical system cables for wear				x	x
Check torque on critical bolt connections				x	x
Check electrolyte level and terminals of battery	(6)		x	x	x
Check engine speed			x	x	x

<b>Service PAK</b>	<b>Notes</b>	<b>Daily</b>	<b>Every 200 hrs</b>	<b>Every 400 hrs</b>	<b>Every 800 hrs</b>
Inspect/Adjust fan belt				x	
Replace fan belt					x
Hoses and clamps - Inspect/Replace			x	x	x
Change engine oil	(2) (5)		x	x	x
Replace engine oil filter	(2)		x	x	x
Replace fuel pre-filter	(5)		x	x	x
Replace fuelfilter	(5)			x	x
Check/Test glow plugs - grid heater					x
Check rubber flexibles	(7)			x	
Check emergency stop		x			
Clean radiator	(1)			x	
Replace air filter element	(1)				x
Check/Replace safety cartridge					x
Inspection by Atlas Copco service technician					x
Inspect starter motor					x
Inspect waterpump					x
Inspect alternator					x
Check engine protective devices					x
Check valve in the fuel return line (for mechanical injection system)					x
<b>Maintenance schedule (km)</b>	<b>Notes</b>	<b>Daily</b>	<b>Every 500 Km</b>	<b>Every 1000 km</b>	<b>Every 2000 km</b>
Check tyre pressure			x	x	x
Check tyres for uneven wear					x
Check torque of wheel nuts					x

**Notes :**

- (1) More frequently when operating in a dusty environment.
- (2) HiLight V4 add 2L oil, HiLight V5+ add 2.5L oil.
- (3) After a days work.
- (4) Change coolant every 2 years, coolant volume is 4L.
- (5) Gummed or clogged filters means fuel starvation and reduced engine performance.
- (6) See section "Before starting".
- (7) Replace all rubber flexibles each 6 years.

<b>Hilight V4</b>	
<b>PAK &amp; KIT</b>	<b>AC PN</b>
SERVICE PAK 200H	3002607610
SERVICE PAK 400H	3002607620
SERVICE PAK 800H	3002607630
KIT: STEEL CABLE	3002608400
STARTER MOTOR	1094150200
FUEL SOLENIOD	1092638800
ELECTRICAL FUEL PUMP	1094066600
FAN	1094150300
V-BELT	1094150500
LIFTING JACK TOP WIND	1092642000
LIFTING JACK SIDE WIND	1092642100
FUEL TANK CAP	1092628639
WINCH RBW 2500	1092870900
LAMP 1000W MH	1092629700
BULB LIGHT TOWER 1000W	1310072643
COIL CORD	1092872301
KEY SWITCH	1092684400
KEY	1094190004
HOUR METER	1092049817
BATTERY HILIGHT V4	1092852000

<b>Hilight V5+</b>	
<b>PAK &amp; KIT</b>	<b>AC PN</b>
SERVICE PAK 200H	3002607840
SERVICE PAK 400H	3002607850
SERVICE PAK 800H	3002607860
KIT: STEEL CABLE	3002608400
STARTER MOTOR	1094150200
FUEL SOLENIOD	1092638800
ELECTRICAL FUEL PUMP	1094066600
FAN	1094150300
V-BELT	1094150500
LIFTING JACK TOP WIND	1092642000
LIFTING JACK SIDE WIND	1092642100
FUEL TANK CAP	1092628639
WINCH RBW 3500	1092871500
Lamp LED	1636004999
COIL CORD	1092872301
KEY SWITCH	1092684400
KEY	1094190004
HOUR METER	1092049817
BATTERY HILIGHT V5+	1092852000

# AML DATA

Reference conditions 1) 4)		HiLight V4 50Hz	HiLight V4 60Hz	HiLight V5+ 50Hz	HiLight V5+ 60Hz
1.Rated frequency	Hz	50	60	50	60
2.Rated speed	rpm	3000	3600	1500	1800
3.Generator service duty		PRP	PRP	PRP	PRP
4.Absolute inlet pressure	kPa	100	100	100	100
5.Relative air humidity	%	0	0	0	0
6.Air inlet temperature	°C	20	20	20	20
<b>Limitations 2)</b>					
1.Maximum ambient temperature	°C	49	49	50	50
2.Altitude capability	m	3500	3500	3500	3500
3.Relative air humidity maximum	%	85	85	85	85
4.Minimum starting temperature unaided	°C	-10	-10	-10	-10
5.Minimum starting temperature aided	°C	-25	-25	-25	-25 (a)
<b>Performance data 2) 3) 5)</b>					
1.Rated active power (PRP) 1ph	kW	5.5	6.5	2.5	2.8
2.Rated power factor (lagging) 1phase	cos f	1.00	1.00	1.00	1.00
3.Rated apparent power 1ph	kVA	5.5	6.5	2.5	2.8
4.Rated voltage 1ph. line to line	V	230	240	230	240
5.Rated current 1ph.	A	23.7	27.0	11.1	11.6
6.Fuel consumption at no load (0%)	kg/h	0.87	1.05	0.28	0.31
Fuel consumption at 1 lamp on	kg/h	1.03	1.28	0.42	0.40

		HiLight V4 50Hz	HiLight V4 60Hz	HiLight V5+ 50Hz	HiLight V5+ 60Hz
Fuel consumption at 2 lamps on	kg/h	1.23	1.51	0.48	0.50
Fuel consumption at 3 lamps on	kg/h	1.45	1.74	0.53	0.57
Fuel consumption at 4 lamps on	kg/h	1.66	1.96	0.69	0.65
7. Specific fuel consumption (at 4 lamps on)	kg/kWh	0.415	0.489	0.172	0.163
8. Fuel autonomy at 4 lamps on with fuel tank	h	55.6	47.2	134.6	142.2
9. Maximum sound power level (LWA) measured according to 2000/14/EC OND	dB(A)	94	95	88	88
10. Capacity of fuel tank	l	110	110	110	110
<b>Application data</b>					
1. Mode of operation		PRP	PRP	PRP	PRP
2. Site		land use	land use	land use	land use
3. Operation		single	single	single	single
4. Start-up and control mode		manual	manual	manual	manual
5. Start-up time		unspecified	unspecified	unspecified	unspecified
6. Mobility/ Config. acc. to ISO 8528-1:1993		mobile/E	mobile/E	mobile/E	mobile/E
7. Mounting		fully resilient	fully resilient	fully resilient	fully resilient
8. Climatic exposure		open air	open air	open air	open air
9. Status of neutral		earthed	earthed	earthed	earthed
<b>Design data 4)</b>					
<b>Alternator</b>					
1. Standard		EN50081-1	EN50081-1	EN50081-1	EN50081-1
		EN50082-1	EN50082-1	EN50082-1	EN50082-1

		HiLight V4 50Hz	HiLight V4 60Hz	HiLight V5+ 50Hz	HiLight V5+ 60Hz
2.Make		Sincro	Sincro	Mecc Alte	Mecc Alte
3.Model		EK 2 MCT	EK 2 MCT	LT3N-75	LT3N-75
4.Rated output,class H temp. rise	kVA	6	7.5	3	4.5
5.Degree of protection	IP	23	23	21	21
<b>Engine</b>					
1.Standard		ISO 3046	ISO 3046	ISO 3046	ISO 3046
		ISO 8528-2	ISO 8528-2	ISO 8528-2	ISO 8528-2
		GB/T 6072.1	GB/T 6072.1	GB/T 6072.1	GB/T 6072.1
		GB/T 2820.2	GB/T 2820.2	GB/T 2820.2	GB/T 2820.2
2.Maker		Kubota	Kubota	Kubota	Kubota
3.Model		Z482	Z482	Z482	Z482
4.Rated output	kW	8.3	9.9	3.4	3.63
production tolerance	%	±5	±5	±5	±5
5.Coolant		PARCOOL	PARCOOL	PARCOOL	PARCOOL
6.Combustion system		direct injection	direct injection	direct injection	direct injection
7.Aspiration		naturally aspirated	naturally aspirated	naturally aspirated	naturally aspirated
8.Number of cylinders		2	2	2	2
9.Swept volume	I	0.479	0.479	0.479	0.479
10.Speed governing		mechanical	mechanical	mechanical	mechanical
11.Capacity of oil sump	I	2.5	2.5	2.5	2.5
12.Electrical system	Vdc	12	12	12	12

		HiLight V4 50Hz	HiLight V4 60Hz	HiLight V5+ 50Hz	HiLight V5+ 60Hz
<b>Power circuit</b>					
<b>Circuit-breaker</b>					
1.Number of poles		1	2	1	2
2.Thermal release	It	A	36.25	36.25	14.5 29 (b) (c)
3.Magnetic release	Im	A	5..10xIn	5..10xIn	5..10xIn
<b>Fault current protection</b>					
1.Residual current release	IDn	A	0.03	0.03	0.03 (a)
<b>Notes</b>					
1) Reference conditions for engine performance to ISO 3046-1 / GB/T 6072.1					
2) See derating diagram or consult the factory for other conditions					
3) At reference conditions unless otherwise stated					
4) Rating Definition (ISO 8528-1 / GB/T 2820.1):					
LTP		Limited Time Power is the maximum electrical power which a generating set is capable of delivering (at variable load), in the event of a utility power failure (for up to 500 hours per year of which a maximum of 300 hours is continuous running). No overload is permitted on these ratings. The alternator is peak continuous rated (as defined in ISO8528-3) at 25°C.			
PRP		Engines with this rating are available for an unlimited number of hours per year in a variable load application. Variable load is not to exceed a 70% average of the Prime Power Rating during any operating period of 250 hours. Total operating time at 100% Prime Power shall not exceed 500 hours per year. A 10% overload capability is available for a period of one hour within a 12-hour period of operation. Total operating time at the 10% overload power shall not exceed 25 hours per year.			
5) Specific mass fuel used: 0.85 kg/l					
(a) optional equipment					
(b) thermal release is higher at 30°C					
(c) thermal release within 1 hour					




# Options

## Spark arresters

### IMPORTANT!

State and local safety codes specify that, in certain locations, internal combustion engines that use hydrocarbon fuels must be used with spark arresters.

A spark arresters is a device constructed of nonflammable materials specifically for the purpose of removing and retaining carbon and other flammable particles from the exhaust flow of an internal combustion engine.



## Tow hitch

There are 3 options for tow hitch.

- Pintle hook
- 2-inch-ball
- Combo hitch for a 2-inch-ball and pintle hook


For combo hitch option only:

When the light tower ships from the factory, the tow bar is set up to use the lunette ring for towing by a vehicle with a pintle hook. To use a ball coupler, follow the procedure below.


To reverse the tow hitch:

1. Remove the two large bolts that hold the tow hitch to the draw bar.
2. Lift the hitch off the drawbar and rotate the hitch end-to-end.
3. Return the hitch to the draw bar, making sure to align the bolt holes.
4. Reinstall the bolts and tighten the nuts fully.


## Towing hitch Combo



## Towing hitch Ball coupling 2 inch



## Towing hitch Ring 2.5 inch




## Control panels


The light tower control panel comprises:

- Circuit breakers for engaging power
- An electrical receptacle for powering external equipment (Option)
- A gauge to track engine use
- Key switch for starting and stopping the engine and a glow-plug indicator for the engine's start coil
- For engine operating instructions, see page 23
- Do not overload machine with socket. Turn off some lamps if you need more power


## Cubicle ELCB with Universal socket 230V 50Hz




## Cubicle ELCB without socket 230V 50Hz




## Cubicle with Universal socket 230V 50Hz




## Road light system




## E-Stop




## Earthing pin




## Battery isolator




## DC E-winch




## Adjustable towing support




# Dimensional drawing - HiLight V5+



# Dimensional drawing - HiLight V5+



# Dimensional drawing - HiLight V4



# Dimensional drawing - HiLight V4

